



- 2. Attach arms to pole at desired height.
- 3. Place the platform over the hole at the end of the arm.
- 4. Insert the Spacer, Washer, and 2.25" Bolt as shown. Tighten.